Canopy Locking Systems
Wiring Diagram

Operation Guide

1   Press 🔒 to lock, Lights flash once (if connected)

2   Press 🔓 to unlock, Light flash twice (if connected)

3   Learning Code

   Open module by levering top of unit away from bottom at 4 x clip points

   Long press learning button 3 seconds, unit is now in learning state

   Within 5 seconds press any button on remote, if connecting more than 1 remote, press one button on each remote within 5 seconds

4   Vehicle locator (Lights must be connected)

   Press 🔒 for 3 seconds, lights will flash 3 times

Green & blue wires on control unit are not used

Brown wire optional for connection to lights

Control Module

Actuator Rear

Actuator Side

Actuator Side

Learning Button

Sw1

Antenna

1	Orange
2	White
3	Yellow
4	Orange/Black
5	White/Black
6	Yellow/Black
7	Black
8	Red
9	Brown — Purple output to parking lights
10	Green — Window rising output(-)
11	Blue — To trunk release -12V

Battery

Clip x 4

Actuator Rear

Actuator Side

Actuator Side